


ST-4000 : Signal Level Meter
Short Form Instructions

HOLLAND
Electronics LLC

Power-On:

Press the Orange colored lower  button

Switching between Off-Air and CATV

With Power off, hold down the Upper left **Scan** button while pressing the Orange  button

Verification of Off-Air or CATV

Enter Ch 14 by pressing buttons **1,4** and **ENT**
The displayed will show CH 014 if set for CATV
or CH 14 if set for Off-Air

Direct Frequency Measurement

Enter 175.25Mhz for example
Press buttons **1, 7, 5, ".", 2, 5** and **ENT**

See www.hollandelectronics.com/support.html for additional information.